



3 Way Point



Switch SW1 is controlled by blades for LH Turn.
 Switch SW2 is controlled by blades for RH Turn.


Note that each colour represents an electrical section of the 3 way point.
 If the switches SW1 & SW2 are not present and the blades aren't touching the stock rails then there will be no connection between the sections.

Route A to X




Switch SW1 is controlled by blades for LH Turn.
Switch SW2 is controlled by blades for RH Turn.

Route A to Y



Switch SW1 is controlled by blades for LH Turn.
Switch SW2 is controlled by blades for RH Turn.

Route A to Z



Switch SW1 is controlled by blades for LH Turn.
Switch SW2 is controlled by blades for RH Turn.